

Bulk Water

FuelMaster Operating Steps

1. Turn wall mounted pump switch to the ON position.
2. Swipe Credit Card.
 - Machine waits for pump selection.
3. Press “1” then “Enter”.
 - Machine asks you if you would like a receipt and waits for your response.
4. Press “Y” for yes or “N” for no.
 - Water will begin dispensing after card authorization (**including \$10.00 Preauthorization**) is completed (five to thirty seconds).
5. Turn wall mounted pump switch to the OFF position after receiving the desired quantity of water.
 - Water will continue to flow for three to ten seconds.
 - Receipt is located in the printer near the bottom of the machine if requested at step 4.

NOTE

- Water is metered in units of ten gallons (or ten cents). Your minimum charge will be ten cents.
- “Car Wash” will be printed on your receipt as the type of service purchased.
- Customer receipts cannot be reprinted.
- If thirty seconds has elapsed after card authorization and the wall mounted pump switch has not been turned on, the machine times out and you must re-swipe your card and start over at Step 1.